

# ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>Access</b>								
AX 600/700/800 U/UL	03-4400	03-10900				05-9400		
<b>Arctic Cat</b>								
500/550/700	03-4600					05-5100		
550/700 Alterra	03-8000	03-8100				05-7800	15-1400	71-9000
1000 XT	03-4500					05-5100		
TRV 500/550/700/1000 (-2016)	03-4200					05-5100		
TRV 500/550/700/1000 (2017+)	03-4200					05-8000		
<b>BRP Can-Am</b>								
Outlander G1	03-1500				05-800	05-3000	15-300	71-3000
Outlander G2	03-3500	03-6300				05-5000*	15-1900*	71-3000
Outlander G2 L	03-3500	03-9900				05-5000*	15-1900*	71-3000
Outlander X MR	03-3500	03-6300				05-5000*	15-1900*	71-3000
Outlander 6x6	03-3500	03-6300				05-7500	15-1900*	71-3000
Renegade G1	03-1500				05-1100	05-3000	15-300	
Renegade G2	03-3500				05-4800	05-5000*	15-1900*	
Renegade X MR	03-3500				05-4800	05-5000*	15-1900*	
Commander (-2014)	03-3800							
Maverick (-2014)	03-4700				05-5600			
Traxter/Defender	03-8700	03-8600				05-7900	15-1900	
<b>Cectek</b>								
500 Gladiator / Quadrift	03-1600							
500 KingCobra	03-1600				05-4000			

## ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>CFMOTO</b>								
500-2/500-2A	03-1800	03-6400			05-3600	05-4900	15-800	
CFORCE X5/X6/X5A/X6A	03-1800	03-6400						
CFORCE 450/520 (-2021)	03-6600		03-6500			05-6900		
CFORCE 450/520 (2021+)	03-6600		03-13300			05-10500	15-1400	
CFORCE 550/600	03-6600	03-5900				05-6700		
CFORCE 625/625 TOURING	03-11300		03-11400			05-9600	15-1400	71-10700
CFORCE 800/820 (X8)	03-3700	03-5900						
CFORCE 850/1000	03-8500	03-8400				05-7700	15-1400	71-10400
CFORCE 1000 Overland	03-8500	03-8400				05-7700	15-1400	71-3000
ZFORCE 550 EX (Z5 EX)	03-5200					05-6300	15-1700	
ZFORCE 600 (Z6)	03-2900				05-3700			
ZFORCE 600 EX (Z6 EX)	03-5200				05-3700			
ZFORCE 800 EX (Z8 EX)	03-5200					05-6300	15-1700	
ZFORCE 1000	03-5200					05-6300	15-1700	
ZFORCE 950/1000 Sport	03-11700			03-11800		05-9700	15-1400	
UFORCE 550	03-4100						15-1300	
UFORCE 600	03-12600			03-12700		05-10300	15-1400	71-11100 71-10850
UFORCE 800	03-4100						15-1300	
UFORCE 1000	03-10000			03-10600		05-9300	15-1400	71-10300 71-7030
<b>CORVUS</b>								
Terrain DX4 (-2021)	03-12200			03-12100				71-10800 71-10900
Terrain DX4 (2021+)	03-12200			03-13300				71-10850
<b>Dinli</b>								
600 Prime	03-2500					05-2500	15-100	
DL 700/702/702L/703/704	03-2500					05-2500	15-100	

## ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>GOES</b>								
520	03-1800	03-6800				05-4900	15-800	
525/625	03-1800	03-6800			05-5500	05-3400	05-3400	
725	03-4400							
UTX 520	03-3000							
Cobalt/Iron	03-6600	03-6800				05-7200 (-2019)		
UTX 700	03-3600							
<b>Hisun</b>								
700	03-3600							
Tactic 550/750 2-UP	03-9000	03-8900				05-8200		71-3000
<b>Honda</b>								
TRX 420 FA (-2013)	03-900				05-5400			
TRX 420 FE/FM (-2013)	03-900				05-5400		15-1100	
TRX 420 FA/FE/FM (2014+)	03-3200		03-6000		05-6100		15-1100	
TRX 420 FA6 (IRS)	03-3200		03-6000		05-6100	05-6800	15-2000	
TRX 450 ES/S					05-1900			
TRX 500 FA	03-1300				05-600			
TRX 500 FA (IRS)	03-3200		03-6000		05-6100	05-6800	15-2000	
TRX 500 FE (-2011)	03-1300				05-600			
TRX 500 FE (2012-2013)	03-3200				05-4300			
TRX 500 FE (2014+)	03-3200		03-6000		05-6100		15-1100	
TRX 520 FA (IRS) (2019+)	03-3200		03-6000		05-6100	05-6800	15-2000	
TRX 650/680	03-1200	03-7500			05-500	05-3200	05-3200	
<b>John Deere</b>								
XUV 590M	03-10400						15-1400	
XUV 865	03-10700							
HPX 815E	03-10800							

## ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>Kawasaki</b>								
KVF 360	03-2300				05-1800			
KVF 650 Rigid	03-300	03-7600			05-100			
KVF 650/750 BruteForce	03-300	03-7600			05-100	05-2800	05-2800	
<b>Keeway (Leone Mastiff)</b>								
XY 500-S/500-L	03-1000							
<b>KUBOTA</b>								
RTV-X900	03-10200							
<b>Kymco</b>								
MXU 250/300	03-2600							
MXU 500	03-1120							
MXU 700 (-2019)	03-9400	03-9300				05-8500		71-3000
MXU 700 (2020+)	03-9400		03-12300			05-10100		
UXV 500	03-2700							
<b>Linhai</b>								
300/400	03-200							
400 IRS	03-2800				05-3500			
500	03-2800		03-10100			05-9200		
550	03-2800				05-5700			
M550/550L	03-2800	03-11100			05-9500	05-9200		
600	03-2800							
<b>ODES</b>								
800	03-9100		03-9200			05-8400		71-3000
650/850/1000	03-12800		03-12900			05-10400	15-1400	

## ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>Polaris</b>								
ACE 325/570/900	03-5600	03-7100			05-6500		15-1200	
Sportsman 400 (2011+)					05-3900			
Sportsman 450/570/ETX/SP (-2020)	03-5000	03-5700			05-3900	05-5300	15-1200	71-4000 71-6000
Sportsman 500 (-2010)	03-1560				05-1200	05-6000		
Sportsman 500 (2011+)	03-1560				05-3900	05-5300	15-1200	
Sportsman 550	03-1700				05-3100	05-2700	15-1200	
Sportsman 570	03-5000	03-5700			05-3900	05-5300	15-1200	
Sportsman 800 (-2010)	03-1100				05-1200			
Sportsman 800 (2011+)	03-1560				05-3900	05-5300	15-1200	
Sportsman 850 (-2014)	03-1700				05-3100	05-2700	15-1200	
Sportsman 850 (2015+)	03-1700	03-6200			05-3100	05-2700	15-1200	
Sportsman 1000 (-2016)	03-1700	03-6200			05-3100	05-2700	15-1200	
Sportsman 1000 (2017+)	03-1700	03-7700			05-3100	05-2700	15-1200	71-6000
Sportsman 1000 S (2020+)	03-11500	03-11600				05-9800	15-1400	71-6000
Sportsman X2 500	03-2200							
Sportsman X2 800	03-1900							
Sportsman Touring 550	03-1700				05-3100	05-2700	15-1200	
Sportsman Touring 570 / X2 / Nordic LE	03-5400	03-5700				05-5300	15-1200	71-4000 71-6000
Sportsman Touring 850 (-2014)	03-1700				05-3100	05-2700	15-1200	
Sportsman Touring 850 (2015+)	03-1700	03-6200			05-3100	05-2700	15-1200	
Sportsman Touring 1000	03-1700	03-6200			05-3100	05-2700	15-1200	
Scrambler 850/1000 (-2014)	03-1700					05-2700	15-1200	
Scrambler 850/1000 (2015+)	03-1700	03-6200				05-2700	15-1200	
Scrambler 1000 S (2020+)	03-11500				05-9900	05-9800	15-1400	
RZR 570	03-7200	03-7300			05-1700	05-7100	15-300	
RZR 800/800S	03-2100	03-7300			05-1700	05-2400		

# ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>Polaris</b>								
RZR 900 XP (-2014)	03-3300			03-7000	05-4400	05-4500		
RZR 1000 XP	03-5500				05-6400		15-1800	
RZR 1000 XP Turbo	03-5500				05-6400		15-1800	
RZR 900S/1000S	03-5500			03-7900	05-6400		15-1200	
RZR PRO XP	03-12000					05-10000	15-1400	
Big Boss 570	03-5400	03-5700			05-3900	05-7400 05-9100	15-1200	71-4000 71-6000
Big Boss 800	03-1100				05-3900		15-1200	
Ranger 400/EV	03-3100			03-7000	05-4200	05-4100	15-1400	71-7000
Ranger 570 (-2021)	03-5100			03-7000	05-4200	05-6200	15-1400	71-7000
Ranger SP 570 (2022+)				03-13500	05-10600		15-1400	71-11400 71-10850
Ranger 570 Nordic Pro (2022+)				03-13800	05-10600		15-1400	
Ranger 800 6x6				03-7000	05-4200		15-1400	71-7000
Ranger 800 Crew				03-7000	05-4200		15-1400	71-7000
Ranger 900 XP	03-4800				05-5900	05-5800	15-1400	71-7000
Ranger 900 Diesel	03-3400			03-7000	05-4200	05-4600	15-1400	71-7000
Ranger Diesel (-2018)	03-4800				05-5900	05-5800	15-1400	71-7000
Ranger Diesel (2019+)	03-4800			03-9800	05-5900	05-5800	15-1400	71-3500
Ranger 1000 (-2020)	03-4800			03-9800	05-5900	05-5800	15-1400	71-3500
Ranger 1000 (2021+)	03-4800			03-9800	05-5900		15-1400	71-3500
Polaris General 1000	03-7800			03-7900		05-7300	15-1400	71-3500
<b>Segway</b>								
Snarler AT6	03-12500	03-12400				05-10200	15-1400	71-11000
Snarler AT6 (2023+)	03-12500	03-14800				05-10200	15-1400	71-11000
Fugleman UT10	03-13100			03-13200			15-1400	
Villain SX10 (2021+)				03-13400			15-1400	

## ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>SMC</b>								
J-MAX 700/700L	03-5800							
MBX 700	03-5800							
<b>Suzuki</b>								
Eiger 400	03-200				05-1600			
KingQuad 450/500/700/750 (-2018)	03-200		03-6100		05-300	05-2600	15-200	71-3000
KingQuad 500/750AXi (EPS)	03-200		03-6100		05-300	05-2600	15-200	71-3000
KingQuad 500/750AXi (2019+)	03-200		03-6100		05-8900	05-9000	15-1400	71-10100
<b>STEELS</b>								
Guepard 850	03-4000	03-11900				03-8600	15-1400	
<b>SYM</b>								
600	03-1110				05-900			
<b>TGB</b>								
425 Blade	03-2400							
550 Blade	03-2400	03-8300			05-6600		15-1400	
600 Blade	03-2400	03-8300				05-7600	15-1400	71-3000
600 LT Blade	03-2400	03-8300				05-7600	15-1400	71-3000
600 LTX Blade	03-2400	03-11000				05-7600	15-1400	
1000 Blade	03-8200	03-8300				05-7600	15-1400	71-3000
1000 LTX Blade	03-8200	03-11000				05-7600	15-1400	
<b>Trapper</b>								
550/750	03-9000	03-8900				05-8200		71-3000

## ADAPTADORES

Modelo	Adaptador de Montagem Inferior	Adaptador de Montagem Dianteira			Suporte de Guincho Dianteiro	Suporte de Guincho Traseiro	Suporte de Bola da Reboque	Adaptador de Basculante
		Padrão	Estreita	UTV				
<b>Yamaha</b>								
Grizzly 450 (2006-2008)	03-2000				05-1400			
Grizzly 450 (2009-2010)	03-600				05-1400			
Grizzly 550	03-600	03-7400			05-200		15-1500	71-3000
Grizzly 660	03-600				05-1300			71-3000
Grizzly 700 (-2013)	03-600	03-7400			05-200		15-1500	71-3000
Grizzly 700 (2014-2015)	03-11200	03-7400			05-200		15-1500	71-3000
Grizzly 700 (2016+)	03-11200	03-6900			05-7000		15-1500 15-2100	71-3000
Kodiak 450 (2017-2021)	03-11200		03-8800			05-8100	15-2200	71-3000
Kodiak 450 (2022+)	03-11200		03-13700			05-8100	15-2200	71-3000
Kodiak 700	03-11200	03-6900			05-7000		15-1500 15-2100	71-3000
Rhino 700	03-700							
Wolverine 700	03-9600				05-8700	05-8800	15-1400	71-3600
Wolverine 700	03-9600				05-8700	05-8800	15-1400	71-3600